



ULTRA SEAT CORPORATION

Operational Guide for the Ultra T772P

Height Adjustment Procedures:

The spring assisted height adjustment is controlled by a height adjustment lever on the front of the suspension. There are 3 height adjustments: bottom, middle & top providing a total height adjustment of 9 1/2".

To Raise: Lift up on the black knob on the top left-hand side of the suspension and take some of your weight off of the seat. When your suspension has come up about 1" release the knob and then push down on the seat and it should lock into place. Repeat the above steps to raise your seat all the way up to its' maximum height.

To Lower: While sitting on the seat, lift the black knob on the top left-hand side of the suspension and push down on the seat until it won't go down any further. Release the knob and your seat should go down into place.

Weight Adjustment:

On the top-middle of your suspension you will find a round knob. This is your weight adjustment. Turn the black handle out of the middle of the round knob and turn it clockwise. As you turn the handle the yellow indicator to the right of the round knob will select the capacity that the seat is set at: If you turn the round knob counter clockwise you will notice the yellow indicator will move in the opposite direction.

Back Angle Adjustment:

The backrest can be set at any position that feels comfortable. To adjust the backrest lift upwards on the black handle (located on the right side of the seat cushion) while pushing or pulling on the backrest of the seat.

Fore and Aft Adjustment:

This seat has 16 different fore and aft positions as approximately 6.5" of travel. The handle for the fore and aft adjustment is located underneath the suspension. Simply lift upwards on the black handle, then push back or pull forward on the seat. It will slide freely. To lock the seat into position let go of the handle. Always test to make sure your seat is locked into place by slightly rocking the seat back and forth.

Pod Armrests:

The pods can be pulled back for better access to the suspension or moved out of the way to make it easier for the operator to get in and out of the machine. In addition the armrest pads can be raised or lowered and moved forward or backwards for operators comfort. Simply turn the black knobs shaped like a star (located under the arm pad on the pod) counter-clockwise to loosen and clockwise to tighten.



ULTRA SEAT CORPORATION

Operational Guide for the Ultra T772P

If your seat is equipped with any accessories: armrest, headrest and/or seat belt

Seat Belt: Gently pull on the belt part of the seat belt. It is located on the left side of the seat under the armrest. The metal end then clicks into the other part of the seat belt on the right side of the seat. After the belt is inserted give the belt a little tug to ensure that it is clicked into place properly. To release the seat belt, push the red button on the seat belt that is attached to the right side of your seat.

Headrest Adjustment: The headrest has 2 different adjustments; up, down, and forward or back. Firmly grip the headrest, than pull up or push down for your desired height. To adjust the tilt, firmly grip the headrest and pull it towards you or push it backwards.