

24-HOUR SUPERVISOR OFFICE CHAIR

- Cloth w/ Ergo Arms & Castor Wheels
- Cloth w/ Ergo Arms & Neoprene Wheels
- Cloth w/ Standard Arms & Castor Wheels
- Cloth w/ Standard Arms & Neoprene Wheels
 - Cloth w/ T Arms & Castor Wheels
 - Cloth w/ T Arms & Neoprene Wheels
- Leather w/ Ergo Arms & Castor Wheels
- Leather w/ Ergo Arms & Neoprene Wheels
- Leather w/ Standard Arms & Castor Wheels
- Leather w/ Standard Arms & Neoprene Wheels
 - Leather w/ T Arms & Castor Wheels
 - Leather w/ T Arms & Neoprene Wheels



Phone: 1-800-667-7328
Fax: 1-888-667-7328
www.ultraseat.com

SUPERVISOR OPERATIONAL GUIDE



ULTRA SEAT CORPORATION



**Product in photo(s) may be different then purchased product,
For additional photos and information please visit
www.ultraseat.com*

STANDARD ARMRESTS

A**Tip-Up Armrests**

To adjust the height use the roller adjuster found on the bottom of the armrest. They can be tilted all the way up when they are not needed.

B**Seat Back Angle Adjustment**

To adjust the backrest lift upwards on the black handle (located on the right side of the seat cushion) while pushing or pulling on the backrest of the seat.

C**Seat Height Adjustment**

Simply pull upwards on the handle closest to the backrest of the chair. Then apply weight to make it go down and sit up to make it higher.

D**Tilt Rocker Adjustment**

To adjust the tilt of your chair lift the middle lever, then lean back on the backrest to desired position. Push down on the lever to lock the tilt angle.

H**A****B****E****C****F****E****Single Air Lumbar**

To increase lumbar support simply pump either the left or right bulbs to desired comfort. To release the air, push the little black button.

F**Weight Adjust./Rocker Tension**

Turn the round dial located at the front on your right side. Turn it clockwise to increase tension and counter-clockwise to release tension.

G**Front Tilt Adjustment**

Simply turn the little handle found under the right side of the seat cushion, clockwise to floor to make the cushion go down or turn it counter-clockwise to make the cushion go up.

H**Adjustable Headrest**

Firmly grip the headrest, then pull or push down for your desired height or pull it towards you to adjust the angle.

For one seated individual. Maintenance Specialist is recommended. Please visit www.ultraseat.com for more information regarding this product.

SUPERVISOR OPERATIONAL GUIDE