

# CONVOY VOLVO ADAPTER INSTALLATION GUIDE

SCAN FOR  
GUIDES






Guides also available at:  
<https://www.ultraseat.com/downloads>

15002208

APPLIES TO  
**CONVOY VOLVO ADAPTER**



1. 3/8" x 1" BOLT (X4)	2. 3/8" FLAT WASHER (X8)	3. 3/8" NYLOCK WASHER (X4)
		

HIGH BASE SHOWN, LOW BASE HOLES ARE IDENTICAL

