

SEAT BASE HOLE PATTERN

V800

Bottom Mounting Pattern

