

SEAT BASE HOLE PATTERN

P200

Bottom Mounting Pattern

