

REFUSE (T774HD)

AUTOCAR ASSEMBLY - INSTALLATION GUIDE

KIT #88059AC - AUTOCAR MOUNTING ADAPTOR				
1.	2.	3.	4.	5.
200184 X2 M8X55MM HEX BOLT	200155 X2 M8X25MM HEX BOLT	200280 X16 3mm SPACER	200216 X4 M8 NYLOCK NUT	88059 X1 MOUNTING PLATE PAIR
				

