


Remove arms according to your seat instructions. If no arms are present, move to Step 2.



Turn the back cover partially inside out leaving enough to grasp and pull over the top of the headrest portion of your seat.



On the front portion of the back cover push the velcro strip through the gap between back of the seat and seat cushion. Pull tight and secure velcro edges together









#350308CK #350309CK





Reinstall your seat arms according to your seat instructions.(If applicable)



Slip the cover over your seat cushion.
Push the back of the cover with the elastic cord loops through the gap between the back of the seat and seat cushion.



Pull the elastic cord with "S" hook around each side of the seat and secure to the elastic loop that you pushed through previously.

Note: If you find the lower portion of your cover loose after installation you may need to tighten the elastic cord with the "S" hooks. To do this, simply untie the knot that holds the "S" hook in place and slide it further down the cord and re-tie the knot.

