

COMMANDER II

OPERATIONAL GUIDE

24
HOUR
OFFICE
CHAIRS

SCAN FOR
GUIDES



Guides also available at:
<https://www.ultraseat.com/downloads>

15002104

UPDATED: 30/11/23

ULTRA
ULTRA SEAT CORPORATION



A

Tip-Up Armrests

To adjust the height use the roller adjuster found on the bottom of the armrest. They can be tilted all the way up when they are not needed.

B

Seat Height Adjust.

Simply pull upwards on the handle closest to the backrest of the chair. Then apply weight to make it go down and sit up to make it higher.

C

Tilt Rocker Adjust.

To adjust the tilt of your chair lift the middle lever, then lean back on the backrest to desired position. Push down on the lever to lock the tilt angle.

D

Weight Adjust./Rocker Tension

Turn the round dial located at the front on your right side. Turn it clockwise to increase tension and counter-clockwise to release tension.

E

Height/Tilt Adjustable Headrest

Firmly grip the headrest, then pull or push down for your desired height.

F

Mechanical Lumbar

To increase lumbar support simply turn the dial left or right to your desired comfort.

G

Seat Back Angle Adjust.

To adjust the backrest lift upwards on the black handle (located on the left side of the seat cushion) while pushing or pulling on the backrest of the seat.

H

Front Tilt Adjust.

Simply turn the little handle found under the left side of the seat cushion, clockwise to floor to make the cushion go down or turn it counter-clockwise to make the cushion go up.

I

Seat Cushion Tilt Adjust.

Lift up on the left hand handle located on the front edge of the seat cushion. Lift up or push down with your legs to achieve desired tilt.

J

Seat Cushion Length Adjust.

Lift up on the right hand handle located on the front edge of the seat cushion. Slide forward or backward to achieve desired length.